


AV ScreenStand Tray Assembly Instructions

1



Place the ScreenStand base upside down.

2



Position the AV Tray onto the base lining up the fixing holes.

3



Using the 4 screws and washers provided, securely fasten the AV Tray to the ScreenStand base.

