

POS Pavement Assembly Instructions



1 Lower the springs connected to the A1 snap frame into the location holes in the moulded base



2 Hold both sections together, lift carefully and lay the sign onto it's side



3 You now have clear access to the underside of the unit to continue assembly



4 Insert a washer and wing nut on to each threaded stud.



5 Tighten firmly by hand



6 Stand the sign upright, unclip all four edges of the snap frame and remove the clear protective cover



7 Insert your poster starting with the top edge, ensuring that the poster is centrally aligned



8 Reposition the protective cover over your poster (textured surface outwards) and snap lock all the frame edge strips to secure in place

The base can be filled with water or fine sand to form an extremely stable assembly

