

BOWHEAD® Assembly Instructions



+44 (0) 844 335 3919

Bowhead and Bowhead device are registered in European Union under numbers 004299475 and 004607636 as the trademarks of Bowhead International.

Exhibition Show .co.uk

1




Remove pole sections, base and graphic from carry bag.

2



Position base where Bowhead is to be displayed. If using the ground spike, locate end of spike above desired location. Ensure strike point is directly above end of spike and, using a suitable mallet, carefully and vertically hammer into ground.

3



Take the pole and allow bungee sections to slide together.

4




Insert flexible pole section into top of assembled bungee pole.

5



Unfold and locate bottom of graphic, then insert top of flexible pole into black tubing of graphic.

6



Slide assembled pole into graphic until flexible pole reaches the end of the graphic.

7



Pull hook on elastic loop of graphic towards clip on assembled pole and attach to secure banner display.

8



Raise pole with attached graphic and align bottom of pole with protruding pin of base.

9

Fully insert pole into base to complete assembly.

